



How to disable the Ink Status Monitor on Canon Printers

Replace/Insert Cartridges.
Open a Document, and select 'PRINT'.
Before it starts to print you may get a message on the screen.
The Message should read:



Just Click OK.

You may then get another message on screen:



If you would like to print press  button for 5 seconds.

However, if the cartridge has been refilled before it was completely empty, this remaining original ink quantity will still be shown on the monitor, in time, when this has been depleted, the above message will then appear.

Please Note: Messages shown above are not to scale, they are just for a rough idea of the original message.